



Instruction for PAIRING CONTROLLER with battery



1. When the battery is not connected to load push both buttons at the same time.



2. The battery will now display a flashing "A"



3. Push the off button on the wireless controller



4. The battery display will now be off or display a flashing "F".

If the battery continues to display "A" and does not respond to the push of the wireless controller then the remote can not match to the battery.